

Sewing Reference Cards

Directions: Print at full scale, cut on outside lines, hole punch, and attach to a keyring.
(Laminate if you'd like extra durability.)

Sewing Machine Maintenance Guidelines

Before each Project: Check to make sure sewing foot and needle are fully attached/inserted and secure. Double check the correct foot is on the machine for your selected stitch.


After each Project: Remove the needle plate, bobbin, and bobbin case. Use the small brush included with all machines to clean out any lint from this area, then reinsert bobbin case, bobbin, and reattach needle plate.

Every 8 hours of Sewing: Insert a new needle in the machine.

Yearly: Take machine to visit your closest Janome dealer or Authorized repair shop for annual maintenance.

Note: Always check your machine manual for oil needs beyond the annual maintenance. Many of our machines are self-oiling and don't require extra beyond what the technician will refill each year.

Sewing Machine Parts



Note: Your machine may have these in slightly different locations, or some features may not be included on your machine. Use the manual included with your machine if you're having trouble locating a specific button/feature.